



- 4- You can either remove the "plug" that keeps the weather stripping in place (a kitchen fork works very well) or you can stretch the rubber past the plug (shown).



- 5- Insert the plugs.



- 6- With the screw and washer provided, install shield.



- 7- It should now look like this:



8- Close hood



9- Tell all your friends about your FANTASTIC new shield from WADE.